

Contents

- 1. Description
 - 1.1 Background information
 - 1.2 Reagent and instrument requirements
- 2. Protocol for the homogenization of tissue for protein extraction

1. Description

1.1 Background information

The isolation of subcellular material such as proteins from tissues or cells requires fast and thorough homogenization of the respective starting material. The gentleMACS $^{\text{\tiny ML}}$ Dissociators provide optimized programs that meet these requirements. In combination with M Tubes, the gentleMACS Dissociators allow the automated homogenization of tissues in a closed system.

This protocol has been developed for the homogenization of tissues to extract cytoplasmic proteins for subsequent analysis such as Western blotting.

1.2 Reagent and instrument requirements

- gentleMACS Dissociator (# 130-093-235)
- gentleMACS Octo Dissociator (# 130-095-937)
- gentleMACS M Tubes (# 130-093-236, # 130-096-335)
- Appropriate lysis buffer for the protein of interest
- (Optional) Antifoam Y-30 emulsion (e.g. Sigma-Aldrich*, # A6457)

2. Protocol for homogenization of tissue for protein extraction

▲ The protocol has been tested successfully for a range of mouse tissues, such as liver, kidney, spleen, heart, lung, brain, skin, muscle, or intestine.

▲ Note: Very hard material such as bone, cartilage, or mouse tail should not be processed since it may damage the M Tubes.

Arr The sample volume should be between 300 μ L and a maximum of 10 mL of lysis buffer. It is recommended to use up to 10 mg tissue per mL of lysis buffer.

▲ Pre-cool lysis buffer on ice.

▲ For details on the use of the gentleMACS Dissociators, refer to the gentleMACS Dissociator user manuals.

Homogenization of tissue for protein extraction

- 1. Choose the gentleMACS Program **Protein_01**.
- 2. Pipette appropriate amount of ice-cold lysis buffer into the M Tube.
- 3. (Optional) To avoid excessive foam formation during sample homogenization, add Antifoam Y-30 to a final concentration of 1% to the lysis buffer.
- Transfer tissue sample into the lysis buffer in the M Tube.
 ▲ Note: Place sample directly into the buffer to avoid adherence of the tissue to the tube wall.
- Tightly close M Tube and turn the tube upside down in one quick move ensuring that the sample material reaches the area of the rotor/stator.
- Attach M Tube upside down onto the sleeve of the gentleMACS Dissociator.
- 7. Run the gentleMACS Program **Protein_01**.
- After termination of the program, detach M Tube from the gentleMACS Dissociator.
- 9. Centrifuge sample at 4000×g for 5 minutes to collect lysate at the tube bottom.
- 10. Store on ice until proceeding with protein analysis.

All gentleMACS Protocols are available at www.miltenyibiotec.com.

Warranty

The products sold hereunder are warranted only to be free from defects in workmanship and material at the time of delivery to the customer. Miltenyi Biotec GmbH makes no warranty or representation, either expressed or implied, with respect to the fitness of a product for a particular purpose. There are no warranties, expressed or implied, which extend beyond the technical specifications of the products. Miltenyi Biotec GmbH's liability is limited to either replacement of the products or refund of the purchase price. Miltenyi Biotec GmbH is not liable for any property damage, personal injury or economic loss caused by the product.

Unless otherwise specifically indicated, Miltenyi Biotec products and services are for research use only and not for diagnostic or therapeutic use.

MACS is a registered trademark and gentleMACS is a trademark of Miltenyi Biotec GmbH

Sigma-Aldrich is a registered trademark of Sigma-Aldrich Biotechnology LP and Sigma-Aldrich Co.

Copyright © 2011 Miltenyi Biotec GmbH. All rights reserved.